

ELNUR

Heat Smarter. Save More.



CUSTOMER GUIDE



Don't switch off at the wall

If you need to turn your heater off, use the small switch on the side of the heater, not the wall switch.



Set different temperatures for each room

Enjoy comfort where you need it and lower bills by using solar energy and off-peak electricity.



Don't use it for drying clothes

This heater isn't designed for drying laundry. Blocking air inlets or outlets can lead to overheating. Always keep air grills clear.



Want to adjust the temperature?

It's easy! Press OK, then press the + or - buttons to set your new temperature. Press OK again to save.



Know your off-peak times

Check with your electricity supplier for your off-peak hours (these can vary). Let your installer know so they can set your heater to charge at the cheapest times. Typical off-peak is 12 midnight to 7 am.



Having a problem?

Call Elnur Technical for support.

Before you call, check:

- Are all wall switches and the heater switch turned on?
- Is your room already warmer than the set temperature?
- Have you accidentally set the temperature too low?